


EXPLODED VIEW & PARTS LIST



Model Number:

FXU18HP230V1R32AO



FXU18HP230V1R32AO

No.	Part Description	Qty	Part No.
NS	Chassis Sub-assy	1	01700006115301P
27	Electrical Heater (Chassis)	1	7651000413
16	Compressor and Fittings	1	009001061222
26	Electrical Heater(Compressor)	1	7651873266
19	Cut off Valve 1/2(N)	1	070001060024
NS	Valve Support	1	012044060035
18	Cut off Valve 1/4(N)	1	070001060022
7	Condenser Assy	1	011002062830
21	Pressure Protect Switch YK-4.6/3.8	1	4602000603
22	Pressure Sensor(HP) 35CP82-04/35CP82	1	43004406002201
20	Pressure Protect Switch 0.05/0.15MPa	1	46020007
28	4 Way Valve Coil 208-230V/60Hz-300	1	07201006000605
17	Electronic Expansion Valve DPF	1	072009060033
14	One Way Valve	1	071001060011
10	Electric Expand Valve Fitting UKV (heating)	1	4304413216
15	Plate-type Heat Exchanger	1	010007060010
12	Electronic Expansion Valve DPF	1	072009060053
NS	Electric Expand Valve Fitting	1	07200206002311
NS	Motor Support	1	01204806019401
8	Brushless DC Motor B-LW92R-ZL(10P)	1	150104060094
9	Axial Flow Fan	1	103002060027
NS	Left Side Plate	1	012055060389P01
NS	Right Side Plate	1	01205606043705P03
1	Electric Box Assy	1	100002083767
3	Main Board	1	300027064362
2	Filter Board	1	300020060166
5	Terminal Board(2 bit)	1	42200006001202
6	Terminal Board(2 bit)(for communication)	1	42200006005601
4	Terminal Board(6 bit)(for communication)	1	422000060106
NS	Jumper	1	4202021916
NS	Jumper	1	30000300000401
NS	Sensor Insert	4	42020063
23	Sensor Sub-assy	1	390002060721
NS	Front Panel Assy	1	000003060713
NS	Front Grill	4	01600406001801
NS	Cabinet	1	01202206001901P01
NS	Top Cover Sub-Assy	2	000051060178
NS	Top cover	1	012049060137P01
NS	Rear Grill	1	01600106008701
24	Drainage hole Cap	3	06813401
25	Drainage Joint	1	2611300901